


Requirements ExtechInstaller with Silicon Labs USB Drivers

1. Two (2) folders will need to be created within the path of the installation application.
2. The ExtechInstaller.exe and Autorun.inf files should be placed application root folder, i.e. **"My Application"**. The Autorun.inf should open the ExtechInstaller.exe.
3. The Silicon Labs USB Driver installation executable file should be placed in the folder named **"USBDrivers"**.
4. The ExtechInstaller installation executable file should be placed in the folder named **"Volume"**.

Example folder layout:



5. ExtechInstaller.exe Configuration:

The configuration can be modified using the Windows Notepad.exe program to edit the ExtechInstaller.exe.config file and modifying the following "add key" line as necessary (see example below).

```
<add key="Softwares" value="Software_Installer.exe"/>
```

Example:

```
<?xml version="1.0" encoding="utf-8"?>
<configuration>
  <startup>
    <supportedRuntime version="v2.0.50727"/></startup>
  <appSettings>
    <add key="UsbDrivers" value="USB_Driver_Setup.bat"/>
    <add key="Softwares" value="Software_Installer.exe"/>
  </appSettings>
</configuration>
```